

# Non-wetting

# **Dry Fog Humidifiers AKIMist**<sub>®</sub>"E"

Compact, efficient, energy-saving humidifiers





# IKEUCHI's Atomization Technology

1

### What is Dry Fog?


Dry Fog is ultra-fine "non-wetting" fog, which doesn't wet the objects it touches. AKIMist® "E" produces a large amount of Dry Fog.

2


### Why is Dry Fog non-wetting?

Small droplets rebound from an object, but large droplets burst and wet the object.

Dry Fog droplets are so fine that they do not burst or wet the objects it touches.



Large droplets




Dry Fog, fine fog droplets

3

# How our Dry Fog is produced

Atomized droplets, sprayed out from the two orifices apart, collide with each other in the center. Simultaneously they generate ultrasonic waves of 33–40 kHz to further atomize the droplets and homogenize their size.



# AKIMist® "E" Installation Example in Many Industries














INDE	X
IKEUCHI's Atomization Technology	1
AKIMist® "E"	3
Optional/Related products	5
► AE-UT Adaptor	5
► Pipe Connection Kits	5
► AKIMist® "E" TN	6
► AE-KIT	6
► AE-T set	6
Installation & Ancillary Devices	7
Benefit of Humidification	9
Customer Case Studies	10
Spray Droplets Size by Various Humidifiers	Back cove

# **AKIMist® "E" Dry Fog Humidifiers**

Compact, efficient, energy-saving humidifiers create quality fog with low air consumption!

### **Dimensions**



### Materials

- Body: PP, Stainless steel 303
- Nozzle: Stainless steel 303, PPS, fluorocarbon resin
- Other parts: NBR, FKM (O-ring, Packing)

### Mass

Approx. 340 g (Loaded)

### Note:

- Before disassembling, close the water valve.
- As main parts are made of plastic, handle AKIMist® "E" with care.
  - (For details, see Instruction Manual.)
- Stop plugs are enclosed to reduce the number of nozzles used.



### Features

- Quality fog reaches over four meters horizontally, providing effective humidification."
- •Up to four nozzles can be mounted per body.
- Compact body structure keeps free from bacteria.
- Automatic humidity control is available with a humidity controller.
  - \*1Spray length depends on the surrounding air temperature and humidity conditions.



### Long life technology

- PTFE nozzle tip is highly resistant to clogging.
- Main parts are quickly detachable by hand.
   Hand-screw plug with built-in packing makes maintenance easier.

### **Applications**

- Humidification: Textile factory, mushroom nursery, poultry incubation, fermentation room, cold storage for food, and more
- Moisture control: Textile, paper, plywood, etc.
- Preventing dust adhesion: Plastic molding, bag-making, painting line
- Dust suppression: Painting line, foundry, ceramic fabrication
- Curing: Concrete
- •ESD prevention/Static electricity control: Printing, textile, painting line, plastic film, plastic molding, assembly line of electronics, paper, and more

# High quality, silky Dry Fog

# Nozzle type 03C

measured by a laser analyzer

Sauter mean droplet diameter: 7-5 µm Spray volume: 2-4 L/hr

03C nozzle type with clog-resistant nozzle tip produces non-wetting Dry Fog (ultra-fine fog) of uniform quality.

Our Dry Fog, with its ability to humidify target spaces without wetting nearby machines or products, is ideal for use in electronics factories or where wetting is not allowed.

### ■03C Nozzle Performance

Air p	ress bar	ure psi	Spray volume in L/hr (GPH)	Air consumption in L/min, Normal (SCFM)
0.2	2	29	1.3 (0.34)	22 (0.82)
0.3	3	44	2.4 (0.63)	29 (1.08)
0.4	4	58	3.1 (0.82)	36 (1.34)
0.5	5	73	3.6 (0.95)	43 (1.60)

Note: Use under the air pressure of between 0.2 and 0.5 MPa (29 and

(per nozzle)	er nozzle) <b>Specifications</b> (per body						
nsumption		Number	at air pressure of	0.3 MPa (44 psi)			
lormal (SCFM)	Model No.	of	Spray volume	Air consumption			
(0.82)		nozzles	in L/hr (GPH)	in L/min, Normal (SCFM)			
(1.08)	AE-1 (03C)	1	2.4 (0.63)	29 (1.08)			
(1.34)	AE-2 (03C)	2	4.8 (1.27)	58 (2.16)			
(1.60)	AE-3 (03C)	3	7.2 (1.90)	87 (3.24)			
MPa (29 and	AE-4 (03C)	4	9.6 (2.54)	116 (4.32)			

One 03C nozzle should be good for spaces of 100 m<sup>3</sup> (3,500 ft<sup>3</sup>), though it depends on various conditions.

# Large volume fog

Nozzle type 04E

Sauter mean droplet diameter: 10 µm measured by a laser analyzer

Spray volume: 3.0 L/hr at 0.3 MPa

04E nozzle type: Scratch-resistant nozzle tip, made of metal.

### ■04E Nozzle Performance

(per nozzle)

■Sį	oec	ifi	ca	ti	0	n	S
				$\overline{}$			

(per body)

Air p	ress	ure	Spray volume	Air consumption
MPa	bar	psi in L/hr (GPH) in L/min, Nor		in L/min, Normal (SCFM)
0.2	2	29	1.9 (0.50)	27 (1.00)
0.3	3	44	3.0 (0.79)	36 (1.34)
0.4	4	58	3.8 (1.00)	45 (1.67)
0.5	5	73	4.5 (1.19)	54 (2.00)

Note: Use under the air pressure of between 0.2 and 0.5 MPa (29 and 73 psi).

	Number	at air pressure of 0.3 MPa (44 psi)		
Model No.	odel No. of nozzles	Spray volume in L/hr (GPH)	Air consumption in L/min, Normal (SCFM)	
AE-1 (04E)	1	3.0 (0.79)	36 (1.34)	
AE-2 (04E)	2	6.0 (1.58)	72 (2.67)	
AE-3 (04E)	3	9.0 (2.38)	108 (4.00)	
AE-4 (04E)	4	12.0 (3.17)	144 (5.34)	

03B type with PTFE nozzle tip and spray volume of 3.3 L/hr per nozzle is also available. For details please contact us.





# Optional/Related products

# **AE-UT Adaptor (optional)**



■Aiming Dry Fog where needed



■Intensive large volume spraying

AE-UT Adaptor enables you to adjust spray direction as desired, just by installing it between the nozzle and the humidifier body. You can easily attach and remove it by hand. Chemical-resistant type is also available.

Note: Stop spraying before you change the direction.


# Pipe Connection Kits (optional)

Convenient pipe connection kits for easy installation of AKIMist® "E". These kits come assembled.

### Hanging-down (NP) Kit (w/o plate)

●Rc 1/4" threaded connection

### **Wall Mounting Kit**




- Bolts for fixing mounting plate are not included
- and need to be prepared by customers.

  The diameters of holes on the plate are 9 mm.

  Rc 1/4" threaded connection.

### Hanging-down Kit



- Bolts and hanging fixture are not included and
- need to be prepared by customers.

  The diameter of hole on the plate is 11 mm.
- Rc 1/4" threaded connection

(03C)

Note: Gray parts are NOT included in the kit. These pipe connection kits are not chemical resistant.

### How to order

Please use this coding system to send an inquiry or to order for a specific model. To add a pipe connection kit, please specify the connection kit type in [ ].

<Example> AE-1 (03C) + [Hanging-down Kit]

Note: Up to four nozzles can be mounted on one AKIMist® "E".

AE-**Number of** nozzles

Nozzle type

**■**(03C) **■**(03B) **2 ■**(04E)

**■**3

Hanging-down Kit

Type of pipe connection kit

- ■Hanging-down (NP) Kit (w/o plate)
- ■Wall Mounting Kit
- ■Hanging-down Kit

### Chemical-resistant AKIMist® "E" TN



nozzle type 03C)

Titanium is applied to the liquid contact parts, for spraying of chemical solution.

Note: This product is sold without pipe connection kit.

### **Applications**

- Disinfection, sterilization in food factories, hospitals/ pharmaceutical plants
- Disinfection, deodorization in egg farms, livestock barns

### **Easy DIY Kit**

# Dry Fog Humidifier Kit

**AE-KIT** 

All the components for an efficient humidification system in one DIY kit. Just supply the electricity and compressed air.

- You can choose the contents of AE-KIT freely to suit your factory size and layout.
- Includes piping and connectors for tap water and air, you can install them easily, and keep optimal humidity. (AKIMist® "E" is installed on a wall.)
- One AE-KIT is good for spaces of up to 800 m<sup>3</sup>. Please contact us for an inquiry sheet.

### Includes:

Nozzle unit (AKIMist® "E"), Control unit, Water (filter) unit, and Piping unit



No piping work!

# Portable Dry Fog Humidifier Set

AE-T set

No piping work necessary. Easy, convenient humidification for immediate usage in any place with an air supply.

- AKIMist® "E" portable humidifier set with a stand unit and water pressure tank. No installation work required.
- Easy automatic control with a humidity controller (optional).
- •Ideal for spot humidification around machinery and use in a small space up to 100 m<sup>3</sup>.

### Includes:

AKIMist® "E", Stand with wheels, Telescopic pole, Water tank, Gauge-mounted pressure regulators, and Mounting unit

Option Compact humidity controller set

### **■**Specifications


Tank capacity	Material	Max. pressure	Mass	Pole height
18 L (4.8 gal)	Stainless steel 304 etc.	0.7 MPa (100 psi)	12.4 kg (loaded: 30.4 kg) 28 lb (loaded: 67 lb)	Min. 1,000- Max. 2,380 mm

Note: Safety valve is set at 0.4 MPa



# **Installation & Ancillary Devices**

For minimal maintenance and long life, clean air and purified water must be supplied to the system. IKEUCHI, having vast expertise, provides a wide range of ancillary devices for purifying water/air and automatic humidity control.



### **Humidity Controllers**

Humidity controller, humidity sensor, and solenoid valve unit work together to provide automated control that maintains the specified humidity level.

### **Humidity Controller (RHC-C11)**

(Compact type with humidity sensor)





- Digital display of present humidity and target humidity
- Compact size to fit any place
- ●Measurement accuracy: +/-3%
- Supply voltage: 100–240 VAC
- Range of operation 0–85% RH (0–50°C)

### **Humidity Controller (RHC-D\*\*B)**

(Controller model numbers are entered in  $^{**}$ .)



\*Humidity sensor is sold separately. (This photo is RHC-D22B)

- Digital display of present humidity and target humidity
- ●Measurement accuracy: +/-3%
- ●Supply voltage: 100-110 VAC or 200-220 VAC
- Using a single controller, up to four zones spread over a wide area can be controlled individually.

### **Solenoid Valve Unit**



A solenoid valve and reducing valve are bundled together as a unit for pressure relief. When the humidifier stops spraying, the remaining air pressure in the piping is instantly relieved, so that only fine fog is sprayed.

### Air Filter

- For removal of dust and moisture contents over 0.3 µm from the compressed air with micro-fiber.
- Available in a variety of sizes.
- Air ancillary device set includes an air filter and oil filter with a manual discharging drain and nipple.



### **Water Filter**

- For removal of foreign particles over 5 μm.
- Available in a variety of sizes.
- Water ancillary device set includes a water filter, a pressure regulator and nipple.




Recommended pipe size chart (when using nozzle type 03C)

- · · · · · · · · · · · · · · · · · · ·						
The total number of	of 03C nozzles	1 2 3 4 5	6 7 8 9	10 11 12 13 14 15 16 17	18 19 20 21 22	23 24 25 26 27 28 29 30 31 32 33
Air consumption	L/min, Normal (SCFM)	29 L/min, Normal (1.08 SCFM) × the number of nozzles				
Water consumption	L/hr (GPH)		2.4 L/hr (0.63 GPH) × the number of nozzles			
Recommended pipe size	Air	1/4" or over	3/8" or over	1/2" or ove	r	3/4" or over
(Stainless steel pipes		//8" or over		1/2" or over		

If you plan to use 03B or 04E nozzles, please contact us.

### Air compressor selection chart (when using nozzle type 03C)



Notes: 1. When spraying at 0.3 MPa air pressure, please refer to the black line ( — ). When spraying at 0.5 MPa air pressure, please refer to the red line ( — ).

- 2. Type of compressor: reciprocating compressor for 0.4-7.5 kW and a screw compressor for 11 kW.
- 3. Using this chart as a target, consult your compressor catalog and confirm the output capacity.

### For minimal maintenance and long life, supply clean air and pure water

The following table shows the required air and water quality specifications to prevent nozzle clogging.


	Air	Water
Pressure	0.2-0.5 MPa (29-73 psi) for 03C/04E 0.3-0.35 MPa (44-51 psi) for 03B at point of use	0.05–0.2 MPa (8–29 psi)  Note: Even if set within given range, water pressure may temporarily exceed 0.2 MPa due to operating and other conditions.  The recommended setting is 0.1 MPa (15 psi).
Temperature	5°C (41°F)–Room temperature	Room temperature
Quality	Air without moisture, oil mist, or dust; Dew point 10°C.	No particles. Electric conductivity = 0.07–10 micro-S/cm (Resistance 14–0.1 M ohm/cm)

# **Benefits of Humidification**

### 1. Static Charge Prevention

Helps to eliminate static electricity problems, improve product quality, and reduce the number of defects.

### ■Relation between humidity and static charge




### 2. Energy-Saving Effect

Our Dry Fog humidification system also yields a cooling of about 2°C, which helps to reduce air conditioning cooling costs.

Energy cost for Dry Fog humidification is only one-fifth of that for steam humidification.

### ■Humidification and cooling effects




### ■Comparison of the operating cost of humidification methods

Comparison of energy costs

80% or more reduction compared with steam humidification


Steam humidifier Steam humidifier Dry Fog humidifier (electrode vapor) (boiler)



### 3. Promoting better worker health

Many of our customers say, "Worker absences caused by illness has reduced after the installation of AKIMist® "E"."

Maintaining a relative humidity level over 50% dramatically reduces cold viruses, flu viruses and so forth, and creates more comfortable working environments.



Humidity over 50% RH cuts the lifespan of cold and flu viruses, helping to reduce worker's sick days.

## **Customer Case Studies**

### 1. Printing

**Web Offset Printing Process** 

Humidity control suited to each printing press type and process has a big impact.

- AKIMist® has quickly gained acceptance as nozzle-type humidification systems are becoming popular in the printing industry.
- AKIMist® has the best track record in the Japanese printing industry, with over 30 years of strong experience.
- For sheet-fed printing, UV printing, Flexo printing and others, we have the best-suited solutions for all kinds of printing presses.



### Improved productivity and quality, reduced waste paper

Paper jams, poor folds, etc. Solved by controlling humidity to around 50% RH

### 2. Electronics SMT Process

# A humidification method that can save energy has become the strongest focus of attention.

- By maintaining humidity at an appropriate level, it is possible to prevent the various problems caused by static electricity.
- The Dry Fog cooling effect reduces the building cooling load.
- •With the No. 1 track record as well as 30 years of remarkably good results, we have optimal solutions for a wide range of processes and environments.
- It is also well-suited for clean room humidification.



### Reduced pickup and mount errors by 60% and cooling load by 20%

Internal part damage Solved by controlling humidity to around 45% RH

### 3. Painting Process for Cars

# Control ambient humidity to eliminate static electricity and limit airborne waste.

- By keeping appropriate humidity, dust is suppressed and static electricity is reduced.
- Humidification is the first step to reduce the adhesion of dust to products.
- Starting with the car industry, AKIMist® is now used in many kinds of industry as the solution for dust problems.
- •We can find solutions to meet the needs of your factory.

# Reduced adhesion of particles 3 Before After the installation of AKIMiste "E" Top coat quality 1.1 1.38 0 Oct. Nov. Dec. Jan. Feb. Mar. Apr.

### Reduced adhesion of dust by 20% and maintaining operators' health

Defective painting by adhesion of dust Solved by controlling humidity to about 50% RH

### **Other Installations**

Field

**Textiles** 

Goal

Improved productivity

- Examples of actual results
- •Thread breakage is prevented and productivity improved.
- Prevented pass weft from sticking.
- Prevented defects due to static electricity.

Chemicals

Safety precautions

- Reduced the risk of ignition in paint and ink mixing processes.
- Allowed humidification for processes where it had been previously thought impossible.
- Reduced risk of fire, which could lead to loss of life and loss of public trust.

We have numerous proven solutions for industries beyond the above cases.


These effects depend on factory conditions.

# Spray Droplet Size by Various Humidifiers

Shown below are pictures of droplets collected by Immersion Sampling and droplet diameter distribution measured by the laser analyzer.


(The vertical axis is for droplet diameter, and the horizontal for the proportional number of droplets.)

### AKIMist® "E" 03C/04E nozzle type (Dry Fog)



### Spinning disk type

Large droplets




Large droplets

Sauter mean droplet diameter: 12.3 µm
......

### Why other humidifiers wet things:

Even though the mean droplet diameter is small, large droplets included in spray distributions will eventually cause wetting.

### ●Ultrasonic type



Note: Specifications and contents noted in this catalog are subject to change without prior notice





ISO9001: 2015 certified (H. IKEUCHI & CO., LTD., Japan only)

### Headquarters

Daiichi Kyogyo Bldg., 1-15-15 Awaza Nishi-ku, Osaka 550-0011, Japan Tel: 81-6-6538-4015 Fax: 81-6-6538-4022 overseas@kirinoikeuchi.co.jp

### IKEUCHI (SHANGHAI) CO., LTD.

Room C, 21F, Electrical & Mechanical Bldg., 600 Hengfeng Road, Shanghai 200070, P.R.China Tel: 86-21-6140-9731 Fax: 86-21-6123-4239

mist@kirinoikeuchi.com http://www.kirinoikeuchi.com/

Tianjin Branch Tel: 86-22-2320-1676 Fax: 86-22-2320-1675 Shenzhen Branch Tel: 86-755-8525-2221 Fax: 86-755-8525-2215 Wuhan Branch Tel: 86-27-8558-8299 Fax: 86-27-6560-5099

### IKEUCHI USA, INC.

4722 Ritter Avenue, Blue Ash, OH 45242, USA

Tel: 1-513-942-3060 Fax: 1-513-942-3064 info@ikeuchi.us https://www.ikeuchi.us/ Georgia Office Tel: 1-706-850-3332 Fax: 1-706-850-3309

### IKEUCHI EUROPE B.V.

Merwedeweg 6, 3621 LR, Breukelen, The Netherlands Tel: 31-20-820-2175 info@ikeuchi.eu https://www.ikeuchi.eu/

### Ikeuchi Taiwan Co., Ltd.

11F-1, No. 27, Sec. 1, Chung Shan N. Rd., Taipei, 10441, Taiwan R.O.C.
Tel: 886-2-2511-6289 Fax: 886-2-2541-6392 sales@ikeuchi.com.tw www.ikeuchi.com.tw/

### PT. IKEUCHI INDONESIA

Ruko Rodeo Drive, Jl. Hollywood Boulevard Blok B6 No. 18 & 19, Jababeka, Bekasi, Jawa Barat 17530 Indonesia Tel: 62-21-8938-4201 (or 4202) sales@ikeuchi.id https://www.ikeuchi.id/

### SIAM IKEUCHI CO., LTD.

-909 Ample Tower Bldg. 8FL., Unit 8/2, 8/3, Debaratana Road, Bangna Nuea, Bangna, Bangkok 10260 Thailand Tel: 66-2-348-3801 Fax: 66-2-348-3802 thai@ikeuchi.co.th https://www.ikeuchi.co.th/

